Speakers



Black boxes marked "HOUSE" are speakers that are controlled by the yellow sliders at the lower right of the mixer marked "House Speakers". These are the only speakers that do not go through the patch bay and cannot be re-assigned.

Codes for these speaker/jack locations are used on the patch bay and on the map above:

AM - jack below the modesty panel in front of section A
AT - jack in tunnel behind section A
AW - speaker above elevator behind the A-F platform
BT - jack in tunnel behind section B
BW - speaker on wall in arena above the recording booth
CM - jack below the modesty panel in front of section C
CW - speaker on wall behind section C (jack by thermostat)
EM - jack below the modesty panel in front of section E
ET - jack in tunnel prop area under section E
EW - speaker on wall behind section E by bass cannon
G - speaker on wall above art gallery
IL - speaker in window room behind section F
FL - speaker on wall in front lobby by vestibule
O - jack in attic above arena
CL1-2 - unterminated
ML - left-monitor speaker on booth ceiling above sound station
MR - right-monitor speaker on booth ceiling above sound station